

Instructions for:

LSMPM Small Probed Mask Kit

LMMPM Medium Probed Mask Kit

LLMPM Large Probed Mask Kit

Quantitative Fit Testing Instructions

1. Remove probed mask from box and leave P100 filters in place.
2. Attach the respirator sample line tubing from the quantitative fit testing instrument to the barbed fitting on the outside of the probed mask.
3. Conduct the quantitative fit test in accordance with the approved OSHA protocol.
4. After fit testing, remove respirator sample line tubing from the barbed fitting on the outside of the probed mask.
5. Clean and sanitize the facepiece following the instructions in the FAMB Instruction Manual.
6. Store the respirator following the instructions in the FAMB Instruction Manual.

Qualitative Fit Testing Instructions

1. Remove probed mask from box and leave the P100 filters in place.
2. Cover the barbed fitting located on the outside of the probed mask. This port must be closed off to ensure that the challenge agent does not leak into the respirator.
3. Conduct the qualitative fit test in accordance with the approved protocol.

NOTE

The Probed Mask includes P100 filters 99.7% effective against particulate aerosols.

4. After fit testing, clean and sanitize the facepiece following the instructions in the FAMB Instruction Manual.
5. Store the respirator following the instructions in the FAMB Instruction Manual.



WARNING

This is a probed facepiece and IS NOT to be used for respiratory protection. DO NOT use to protect against respiratory hazards or contaminants. It is to be used ONLY by properly trained and qualified personnel for fit testing and to monitor contaminant levels inside the facepiece.

Americas:
E.D. Bullard Company
1898 Safety Way
Cynthiana, KY 41031-9303
Toll free: 877-BULLARD (285-5273)
Tel: 859-234-6616
Fax: 859-234-8987
www.bullard.com

Europe:
Bullard GmbH
Lilienthalstrasse 12
53424 Remagen • Germany
Tel: +49-2642 999980
Fax: +49-2642 9999829
www.bullardextrem.com

Asia-Pacific:
Bullard Asia Pacific Pte. Ltd.
LHK Building
701, Sims Drive, #04-03
Singapore 387383
Tel: +65-6745-0556
Fax: +65-6745-5
www.bullard.com

©2009 Bullard. All rights reserved.



6088008811A (0209)